

A R K A N O I D

"G" CONNECTOR

<u>COMPONENTS SIDE</u>		<u>SOLDER SIDE</u>
GND	1	GND
VIDEO RED	2	VIDEO GND
VIDEO GREEN	3	VIDEO BLUE
VIDEO SYNC	4	
SOUND OUT (+)	5	SOUND OUT (-)
POST	6	POST
	7	
COIN SW (A)	8	COIN SW (B)
COIN METER (A)	9	COIN METER (B)
COIN LOCKOUT (A)	10	COIN LOCKOUT (B)
SERVICE SW	11	TILT SW
SELECT-1	12	SELECT-2
	13	
	14	
1P RIGHT	15	2P RIGHT
1P LEFT	16	2P LEFT
	17	
	18	
	19	
	20	
1P SERVE/FIRE	21	2P SERVE/FIRE
	22	

"H" CONNECTOR

	1	GND
	2	GND
	3	GND
	4	GND
	5	+5V
	6	+5V
	7	+5V
	8	
	9	+13V
	10	POST
	11	
	12	

DIP SW

	1	2	3	4	5	6	7	8
Play Pricing								
1coin 1credit	OFF	OFF						
1coin 2credit	ON	OFF						
2coin 1credit	OFF	ON						
1coin 6credit	ON	ON						
Number of Player								
3					OFF			
5					ON			
Bonus Points 1st/Every								
20,000/60,000					OFF			
20,000 Only					ON			
* Game Difficulty								
Rank A (Easy)						OFF		
Rank B (Hard)						ON		
Test Mode								
Normal Game							OFF	
Test Mode							ON	
Screen Inversion								
Normal								OFF
Inversion								ON
Continued Play								
Without								OFF
With								ON

* Game Style --- Up Right Type Only.

Note) Before changing the settings of the DIP SW, turn the power switch "OFF".