

# Super ABC Settings and Instructions

## DIP Switch Settings

Option (* = recommended)	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
Free Play	ON	ON						
1 Coin 1 Credit *	OFF	ON						
1 Coin 2 Credits	ON	OFF						
2 Coins 1 Credit	OFF	OFF						
1 Pacman Per Game			ON	ON				
2 Pacman Per Game			OFF	ON				
3 Pacman Per Game *			ON	OFF				
5 Pacman Per Game			OFF	OFF				
Bonus Player @ 10000 Pts *					ON	ON		
Bonus Player @ 15000 Pts					OFF	ON		
Bonus Player @ 20000 Pts					ON	OFF		
No Bonus Players					OFF	OFF		
Free Game in ULTRA PAC / Buy-in ON *						ON		
Free Life in ULTRA PAC / Buy-in OFF						OFF		
Auto. Rack Advance (Skip)							ON	
Normal- Must be off for game play *							OFF	
Freeze Video (Pause)								ON
Normal- Must be off for game play *								OFF

### **Note concerning DIP SWITCH #6:**

During the game ULTRA PACMAN there is a rare 'butterfly', which appears. Eating the butterfly awards the player either an extra man or an extra credit depending on the setting of DIP switch #6. DIP SWITCH #6 ALSO turns the BUY-IN feature ON and OFF.

---

## Clearing the high score table and checking the bookkeeping

Enter test mode via the cabinet switch located near the coin door hinge. Then hold the ONE PLAYER DOWN and ONE PLAYER START switches simultaneously for approximately 7 seconds and follow the on-screen directions.

---

**Two-Bit Score Amusements**  
**4418 Pack Saddle Pass**  
**Austin, TX 78745**  
**512-447-8888 Voice**  
**512-447-8895 Fax**